# RABBIT

#### OVERVIEW

# All products by The Rabbit Company<sup>TM</sup> are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.

#### The Mini Rabbit™






#### GETTING STARTED

1. Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (Not included).



- · Flashing Light = Charging
- · Solid Light = Fully Charged





3. Lubricate your rabbit (if needed) with a water based, silicone compatible lubricant.



- 4. Press the 🖒 button turn the item ON.
- **5.** To change the vibration pattern, press and release (1)
- 6. Press the **(**) button 3 seconds again to turn off.

# CONTROLLING YOUR RABBIT

- ullet Press the ullet button turn the item ON.
- Press the 🖒 button 3 seconds again to turn off.



Turn On/ Change Vibration



iurii Oii

#### TRAVEL LOCK

• To enable the travel lock, press and hold the device b button for 3 seconds while the device is off. The LED-indicator will flash twice indicating that the device is locked.

To disable the travel lock, press

- and hold the device  $\bigcirc$  button for 3 seconds. The LED-indicator will flash twice indicating that the device is unlocked.
- Plug the USB charging cable into any USB port or USB/AC power adapter (Not included) to disable the travel lock



#### CHARGING

- Insert the charging plug in the designated charging area
- Flashing light indicates item is charging
- Solid light indicates item is fully charged
- Rabbits require approximately 2 hours for full charge




Flashing Light = Charging





#### VIBRATION PATTERNS



### HARE CARE™

## Cleaning, Storage & Safety

- 1. Always clean your Rabbit thoroughly before and after each use.
- 2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.
- 3. To properly clean your rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an antibacterial soap. Rinse clean and





pat dry using a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.

- Avoid leaving your rabbit in direct sunlight and never expose it to extreme heat.
- 5. The mini rabbit is waterproof. After use in the bath/ shower, please make sure to completely and thoroughly dry before storage. For best product performance, limit bathub use to 15 minutes and no longer than 30 minutes





...

#### **SPECIFICATIONS**

Materials

Body Safe ABS / Silicone

Size

28 x 54 x 139 mm

Weight

82 g

Battery Li-ion 300 mAh Charging

Use Time

Max Noise Level

<68 db

Interface

7 vibration patterns

# DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

1









Complete user instructions in additional languages can be found at:

#### www.TheRabbitCompany.com

Designed and Developed by The Rabbit Company™

Made in China © The Rabbit Company™ The Delah in Comment