


TINGON Vibrating Nipple Clamps N1

User Manual



Scan the QR code for more information




Tin9 | *Enjoy More*

X

Focus On Dopamine Pleasure

TINGON dopamine toys are the ultimate in quality. With beautifully crafted designs guided by expert insight and extensive research, our collection has been created to empower people to explore a new world of intimate -and infinite – possibilities.



Safety Tips

- This product is for personal use only and should not be used in other institutions or public places.
- This product is designed solely for personal and private use. Please do not use it for any other purpose.
- This product contains non-removable built-in capacitors. Do not attempt to replace them yourself.
- Do not modify, disassemble, or repair this product yourself.
- Avoid dropping or striking the product. Do not use the product if it is damaged
- Do not block the heater vents to prevent short-circuiting or fire
- Please use an adequate amount of lubricant when using the product to avoid discomfort.
- After use, disconnect the power supply first. When unplugging the power cord, grasp the firm part of the plug with your hand. Do not pull or tug on the power cord forcefully, or use it to drag the product.
- Use only genuine and compatible TINGON original accessories with this model.
- Do not place the product or its capacitor near high temperatures or heating devices such as sunlight, microwaves, heaters, or ovens, as overheating may cause explosions.
- Use this product within an ambient temperature range of 5°C to 35°C and store the product and its accessories within a temperature range of 5°C to 45°C.
- If you have diabetes or other medical conditions, consult a doctor before use.
- Store the product in a clean place away from direct sunlight and out of reach of children.

Package Contents

- 1 Nipple Clamp Controller
Hanging Rope x1
- 2 Magnetic Charging Cable x1

RoHS CE  UK
CA  FCC

Package Contents


Model	TINGON N1
Materials	ABS + Silicone
Dimensions	Product + Cable length 602mm
Net weight	20.2g
Vibration Modes	12 modes
TINGON APP	Available for download on the official TINGON website Usage
Operating Time	- minutes
Charging Time	- minutes
Waterproof Rating	IPX6
Operating Noise	< ** decibels

TINGON APP



(Scan the QR code to visit the TINGON official website. Download the app based on your Android or Apple device. After successful registration, you can connect to all products in the series and enjoy more diverse features and synchronized interactive functions.)

Instructions for Use




Switch Control: Press and hold the power button for 1.5 seconds to power on or off. After powering on, the button indicator light and battery indicator light will illuminate simultaneously.

Vibration Mode Selection: After powering on, toggle through the 12 vibration modes by single-clicking the power button. Modes cycle sequentially.

Battery Status Indicator: When turned on, the battery indicator light will illuminate to indicate real-time battery level. During charging, the indicator light will breathe in response to the battery percentage, gradually increasing from low to high, and remain steady when fully charged.

Charging Description



Notes

1

Before using the product, please ensure it is fully charged by correctly aligning the magnetic charging cable with the charging port. During normal charging, the battery indicator light will blink. When the battery is fully charged, the indicator light will remain on continuously. Before using the product, clean the applicable areas with warm water or a specialized cleaner, and gently dry with a towel.

2

This product is not suitable for use on swollen or inflamed skin areas to avoid injury or exacerbating discomfort.

3

After each use, rinse the product with warm water and antibacterial soap, then rinse thoroughly with clean water. Do not immerse the entire device in water for cleaning. Finally, gently dry any remaining moisture with a towel.

4

The device should not be operated while charging. Do not turn on the device during charging, and avoid charging near water.

Product Cleaning

After use, this product can be rinsed under a moderate water flow. After rinsing thoroughly, it is necessary to completely dry the product and the magnetic charging port. (Do not immerse in water for use.)

